
USER'S MANUAL



ENGLISH



SRK25ZMP-S SRK35ZMP-S SRK45ZMP-S MANUEL DE L'UTILISATEUR FRANÇAIS

CLIMATISEUR

KLIMAGERÄT

ANWENDERHANDBUCH

DEUTSCH

ISTRUZIONI PER L'USO

CONDIZIONATORE D'ARIA

ACONDICIONADOR DE AIRE

ITALIANO

MANUAL DEL PROPIETARIO

ESPAÑOL

GEBRUIKERSHANDLEIDING

NEDERLANDS

AIRCONDITIONING

MANUAL DO UTILIZADOR PORTUGUÊS

APARELHO DE AR CONDICIONADO

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

ΕΛΛΗΝΙΚΑ

ΚΛΙΜΑΤΙΣΤΙΚΟ

РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

РУССКИЙ

КОНДИЦИОНЕР ВОЗДУХА

KULLANIM KILAVUZU

TÜRKÇE

SPLIT KLIMA

((

This air conditioner complies with EMC Directive 2004/108/EC. LV Directive 2006/95/EC.

Este acondicionador de aire cumple con la directiva FMC: 2004/ 108/EC, LV Directiva 2006/95/EC.

Ce climatiseur est conforme à la Directive FMC: 2004/108/FC TV Directive 2006/95/EC

Deze airconditioner voldoet aan EMC Directive 2004/108/EC. LV Directive 2006/95/EC

Dieses Kimagerät erfüllt die EMC Direktiven 2004/108/EC, LV Direktiven 2006/95/EC.

Este aparelho de ar condicionado está em conformidade com a Directiva EMC 2004/108/EC e a Directiva LV 2006/95/EC

Questo condizionatore d'aria è conforme alla Direttiva EMC: 2004/ 108/EC. LV Direttiva 2006/95/EC.

Αυτό το κλιματιστικό είναι σύμφωνο με τις προδιαγραφές της Οδηγίας ΕΜC 2004/108/ΕΚ και της Οδηγίας LV 2006/95/ΕΚ.

RLC012A003A

Thank you for purchasing a MITSUBISHI HEAVY INDUSTRIES, LTD. Air-Conditioner. To get the best long-lasting performance, please read and follow this User's Manual carefully before using your air-conditioner. After reading, please store the Manual in a safe place and refer to it for operational questions or in the event of any irregularities.

This air-conditioner is intended for domestic use.

Do not vent R410A into the atmosphere: R410A is a fluorinated greenhouse gas, covered by the Kyoto Protocol with a Global Warming Potential (GWP) = 1975.



Your Air Conditioning product may be marked with this symbol. It means that waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) should not be mixed with general household waste. Air conditioners should be treated at an authorized treatment facility for re-use, recycling and recovery and not be disposed of in the municipal waste stream. Please contact the installer or local authority for more information.



This symbol printed in the batteries attached to your Air Conditioning product is information for end-users according to the EU directive 2013/56/EU article 20 annex II.

Batteries, at their end-of-life, should be disposed of separately from general household waste. If a chemical symbol is printed beneath the symbol shown above, this chemical symbol means that the batteries contain a heavy metal at a certain concentration. This will be indicated as follows: Hg:mercury(0.0005%), Cd:cadmium(0.002%), Pb:lead(0.004%) Please, dispose of batteries correctly at your local community waste collection or the recycling center.

The emission sound pressure level from each Indoor and Outdoor unit is under 70 dB(A).

contents

Safety precautions 2	SLEEP TIMER operation 13
Name of each part and its function 6	OFF-TIMER operation 13
Remote control handling 8	ON-TIMER operation 14
Operation failure with the remote control 8	SLEEP TIMER + ON-TIMER operation 14
Temporary run operation 8	PROGRAM TIMER operation 15
Operation and display section for remote	HIGH POWER/ECONOMY operation 16
control9	SELF CLEAN operation
Current time setting	Auto restart function
AUTO mode operation 10	Tips for effective operation 17
Temperature adjustment during AUTO 10	Maintenance 18
FAN SPEED 10	Proper installation
COOL/HEAT/DRY/FAN mode operation 11	Troubleshooting
Air-conditioner operable	Notice
temperature setting 11	Contact your dealer21
Characteristics of HEAT mode operation 11	Self diagnosis function
Airflow direction adjustment 12	

ENGLISH

Safety precautions

- Before starting to use the system, please read these "Safety precautions" carefully to ensure proper operation of the system.
- When you have read this instruction manual, please keep it without missing. If someone else takes over as operator, make certain that the manual is also passed on to the new operator.

△ WARNING	Improper handling could lead to drastic result like death, serious injury, etc.
△ CAUTION	Might pose a serious problem, depending on the circumstances.

Please observe these precautions with great care, since they are essential to your safety.

• Symbols which appear frequently in the text have the following meaning:

\Diamond	Strictly prohibited	0	Observe instructions with great care	•	Provide proper earthing
------------	---------------------	---	--------------------------------------	---	-------------------------

■ INSTALLATION PRECAUTIONS

△ WARNING



• The system is for domestic, residential etc. use.

If used in severer environments, such as an engineering workplace, the equipment





The system must be installed by your dealer or a qualified professional.
 It is not advisable to install the system by yourself, as faulty handling may cause leakage of water, electric shock or fire.

A CAUTION



• Do not install it where flammable gas may leak.
Gas leaks may cause fire.



 Depending on the place of installation, an earth leakage breaker may be necessary.

If you do not install an earth leakage breaker, you may get an electric shock.

 Make sure to install the drain hose properly so that all the water is drained out.

Improper installation may lead to water drop in the room resulting in wet furniture.



• Make sure that the system has been properly earthed.

Earth cables should never be connected to a gas pipe, water pipe, lightning conductor or telephone earth cable. Incorrect installation of the earth cable may produce an electric shock.

■ OPERATION PRECAUTIONS

↑ WARNING



- Children shall not play with the appliance.
- Do not expose yourself to the cooling air for a long period.

This could affect your physical condition and cause health problems.

- Cleaning and user maintenance shall not be made by children without supervision.
- Do not insert anything into the air inlet.

This may cause injury, as the internal fan rotates at high speed.



- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Store the remote control out of reach of infants.

 Failure to observe this may result in the batteries being swallowed or other accidents.

A CAUTION



- Only use approved fuses.
 - Use of steel or copper wire instead of an approved fuse is strictly prohibited, as it may cause a breakdown or fire.
- Do not handle the switches with wet hands.

This may cause an electric shock.

- Do not swing from the indoor unit.
 If the indoor unit falls down, you may get injured.
- Do not place a flammable insecticide or paint spray near the blower, nor spray it directly on the system.

This may result in a fire.

 You should not expose any combustion appliance directly to the air stream of the air-conditioner.

The appliance may then work inadequately.

 Do not wash the air-conditioner with water.

This could cause an electric shock.

 The system should only be used for its original purpose and not for anything else like, for instance, preservation of food, plants or animals, precision devices or works of art.

The system is only intended for use in ordinary domestic rooms. Any other use of the system may damage the quality of food, etc.

- Do not place anything containing water, like vases, on top of the unit.
 Water entering the unit could damage the inpulstion and therefore gauge an
 - the insulation and therefore cause an electric shock.
- Do not install the system where the airflow direction is aimed directly at plants or animals.

This will damage their health.

 Do not sit on the outdoor unit nor put anything on it.

If the unit falls down or things drop off it, people could get hurt.

 After a long period of use, check the unit's support structure from time to time.

If you do not repair any damage right away, the unit may fall down and cause personal injury.

A CAUTION



 Do not touch the aluminum fins on the air heat exchanger.

It may result in injury.

 Do not place household electrical appliances or household items under neath the indoor or outdoor units.
 Condensation falling from the unit may stain objects and cause accidents or electrical shock.

 Do not operate the system without the air filter.

It can cause malfunction of the system due to clogging of the heat exchanger.

 Do not shut off the power supply immediately after stopping the operation.

Wait at least 5 minutes, otherwise there is a risk of water leakage or breakdown.

 Do not control the system with main power switch.

It can cause fire or water leakage. In addition, the fan can start unexpectedly, which can cause personal injury.

 Do not pour liquid into this unit and do not put water container on this unit.
 Water entering the unit could damage the insulation and therefore cause an electric shock.



 If you operate the system together with a combustion appliance, you must regularly ventilate the indoor air.

Insufficient ventilation may cause accidents due to oxygen deficiency.

 Stand firmly on a stepladder or other stable object when removing the inlet panel and filters.

Failure to observe this may result in injury through insecure objects toppling over.

- When you clean the system, stop the unit and turn off the power supply.
 Never open the panel while the internal fan is rotating.
- Do not place objects near the outdoor unit or allow leaves to gather around the unit.

If there are objects or leaves around the outdoor unit, small animals may enter unit and contact electrical parts and may cause a break-down, smoke or fire.

 Contact your dealer to clean inside the indoor unit, do not attempt to do by yourself.

The use of a non-approved detergent or improper washing method may damage the unit's plastic components and cause leaks. Damage, smoke, or fire may also happen if the detergent comes in contact with electrical parts or the unit's motor.

 Stop the unit and turn off the power if you hear thunder or there is a danger of lightning.

It may damage the unit.

 Do not let the foreign matters enter the indoor unit through the air outlets.

This may cause the dumper inoperable.

 If the power cord becomes damaged, contact your dealer or a qualified engineer.

If it is not replaced, it may cause a breakdown or fire.

■ PRECAUTIONS FOR RELOCATION OR REPAIRS

⚠ WARNING



• Do not perform any repairs or modifications by yourself. Consult the dealer if the unit requires repair.

If you repair or modify the unit, it can cause water leaks, electric shocks or fire.



- Consult your dealer for repairs.
 Wrong repairs could cause an electric shock, fire, etc.
- In case the air-conditioner is relocated elsewhere, contact your dealer or a professional fitter.

Faulty installation may cause water leakage, electric shock, fire, etc.


 If you notice anything abnormal (smell of burning, etc.), stop the system, turn off the power supply and consult your dealer.


Continued use of the system in abnormal circumstances may result in malfunctioning, electric shock, fire, etc.

 If the air-conditioner fails to cool or warm the room, it may have a refrigerant leakage. Contact your dealer.
 If refrigerant needs to be added, check with your dealer for proper instructions.

If the refrigerant comes in contact with the bare skin, it may cause cold injury. If the refrigerant gas is inhaled excessively, it may cause deterioration of nerve function like dizziness and headache, or deterioration of heart function like irregular heartbeat and heart palpitation temporarily. If refrigerant unexpectedly leaks from the unit onto a fan heater, stove, hotplate or other heat source, harmful gases could be generated.


Name of each part and its function





Name of each part and its function

Unit display section



Accessories



Wireless remote control



Wireless remote control holder



(R03 (AAA, Micro) x2)




Wood screw (Quantity:2) (for remote control holder mounting)

NOTE

Buzzer sound for remote control

When preset temperature 24°C, automatic operation and automatic airflow are selected, the buzzer sound (PiPi) is produced. When turning off the air conditioner by pressing ON/OFF button (except CLEAN mode), the buzzer sound (Pi) is produced. This function is useful for operating the air conditioner in the darkness.

Air flow setting



Preset temperature


$$22 \stackrel{\Rightarrow}{\leftarrow} 23 \stackrel{\Rightarrow}{\leftarrow} 24 \stackrel{\Rightarrow}{\leftarrow} 25 \stackrel{\Rightarrow}{\leftarrow} 26$$
PI PI PI PI PI PI


Remote control handling

Replacing the batteries


The following cases signify exhausted batteries. Replace old batteries with new ones.

- Receiving beep is not emitted when a signal is transmitted.
- Display fades away.





Close the cover.



The timer setting mode is displayed.



Page 9




- Do not use old and new batteries together.
- Remove the batteries when the remote control is not used for a long period.
- The recommended effective period of a battery conforming to JIS or IEC should be 6 to 12 months with normal use. If used longer, or when an unspecified battery is used, liquid may leak from the battery, causing the remote control to
- The recommended effective period is printed on the battery. This may be shorter due to manufacturering time to the unit. However, the battery may still be in working order after expiry of its nominal life.
- When the display shows any abnormal condition, Press the ACL switch with the tip of a ballpoint pen.

Using the remote control holder

The remote control can be attached to a wall or pillar by using a remote control holder. Before installing the remote control, check that the air-conditioner receives the signals properly.

For installing or removing the remote control, move it up or down in the holder.



Warning note for remote control handling

Strictly prohibited Do not go near high temperature Do not leave the remote control ex-Do not drop the remote control. posed to direct sunlight or other places, such as an electric carpet Handle with care. or stove. strong lighting. Do not put any obstructing obsta-Do not spill any liquid on the Do not place heavy objects on the cles between the remote control remote control. remote control, or step on it. and the unit.

Operation failure with the remote control

Are the batteries running down?



"Replacing the batteries" above.

Replace the batteries with new ones and retry the operation.

If the operation fails, operate the unit with temporary operation function. Contact your dealer to have the remote control



Temporary run operation


The unit ON/OFF button on the unit operates ON/OFF temporarily when the remote control is not used.

Operation program -

• OPERATION MODE: AUTO FAN SPEED **AUTO**

 AIR FLOW AUTO


Operation starts by pressing the unit ON/OFF button; it stops if you press the button again.





Do not hold the Unit ON/OFF button down for more than 5 seconds. (Holding it down longer than 5 seconds sets the automatic cooling used during servicing or when relocating the air-conditioner.)

Operation and display section for remote control




Transmission procedure

When each button on the remote control is pressed – with the remote control pointing towards the air-conditioner unit a signal is transmitted. When the air-conditioner receives the signal correctly, it will beep.

Current time setting

When inserting the batteries, the current time is automatically set to time setting mode. 13:00 is displayed as the current time. Set the clock to the right time.



Example: Set to 10:30.

Press the ACL switch.

The time display blinks and can be set to the current time.

Press with the tip of a ballpoint pen, etc.

Press the △ or ⊘ button.

(Set to 10:30)

Press the ON/OFF button.


The display changes from blinking to steady lighting and the setting is complete. Make sure to press the button within 60 seconds from the last operation in step 2, otherwise the time is not set.

NOTE

- The timer operation works based on the time clock, so please set it correctly.
- The remote control data is reset when the present time is set.


AUTO mode operation

■ Automatically selects the operation mode (COOL, HEAT, DRY) depending on the room temperature when switched on.





Point the remote control toward the air-conditioner, and







. In case air is not blowing out during the operation.



Display in OFF status



 The current time and preset OPERA-TION MODE are displayed while the air conditioner is turned off. If you do not want the AUTO mode program, change to COOL, HEAT, DRY or FAN instead of AUTO.




· Airflow direction adjustment procedure.



Temperature adjustment during AUTO

■ Air temperature adjustment is possible even during automatic operation. There are 6 levels of adjustment possible with the o button or the o button. During automatic operation, 24°C is preset both for heating and cooling.



FAN SPEED

You can choose the capacity of your air-conditioner when heating mode, cooling mode or fan mode.

Operation capacity by your choice	FAN SPEED
Set automatically by microcomputer	AUTO
Powerful operation with high capacity	HI
Standard operation	MED
Energy-saving operation	LO

Press the FAN SPEED button.

Move the [■ mark] to the preferred fan speed position.

 \longrightarrow AUTO \longrightarrow HI \longrightarrow MED \longrightarrow LO -



 When changing FAN SPEED from HI to LO, the sound of refrigerant flowing may be heard.

COOL/HEAT/DRY/FAN mode operation

AN SPEED ON/OFF MODE

PAN SPEED ON/OFF MODE

ARRIOW

ON TIMER

SLEEP CANCEL

CLEAN ACL

Airflow direction adjustment procedure. Page 12

Point the remote control toward the air-conditioner, and

Press the MODE select button.

Move the [■ mark] to the required operation position.

※ (Cool), ☆ (Heat), △ (Dry), 左(Fan)

Press the ON/OFF button.

Press the TEMP button.

Recommendation

| 26°C~28°C | 型 22°C~24°C | 품 24°C~26°C | 長 | --

Press the FAN SPEED button
Set the fan speed as preferred.

To stop:

Press the ON/OFF button.

NOTE NOTE

- In case air is not blown out, when starting the heating operation.

 Page 20
- The operation program can also be set or changed when the air-conditioner is not in operation.

Air-conditioner operable temperature setting

Use within the following operational range. Operating outside of this range may result in the protection devices being activated, preventing the unit from working.

	Cooling operation	Heating operation
Outside temperature	Approximately -15 °C to 46 °C	Approximately -15 to 24 °C
Inside temperature	Approximately 18 to 32 °C	Approximately 15 to 30 °C
Inside humidity Below approximately 80% The long-term use of the unit with a humidity level exceeding 80% may result in condensation forming on the surface of the indoor unit, leading to water drips.		_

Characteristics of HEAT mode operation

Mechanism and capacity of HEAT mode operation

■ Mechanism

- The unit draws heat from the cold outside air, transfers it to indoors and heats the room. As a characteristic of heat pump system, the heating capacity reduces when the outside air temperature gets colder.
- · It may take some time to supply hot air after turning on the air-conditioner.
- If the outside temperature becomes extremely low, it would be better to use an additional source of heating.

Defrosting

If the outside temperature becomes low and humidity is high, the heat exchanger in the outdoor unit may frost over, which prevents efficient heating.

If this happens, the automatic defrost function is activated and during defrosting the heating operation stops for 5 to 15 minutes during defrosting.


- Both indoor and outdoor fans stop and the RUN light blinks slowly (1.5 sec. ON, 0.5 sec. OFF) during defrosting.
- . The outdoor unit may give off some steam during defrosting. This is to help the defrosting process and is not a defect.
- The HEAT operation resumes as soon as defrosting has been completed.

Airflow direction adjustment

Adjusting airflow direction

■ Up/down direction can be adjusted with the AIRFLOW button on the remote control. Every time you press this button the mode changes as follows:

Change on AIRFLOW (UP/DOWN) mode.



NOTE FOR HEATING OPERATION

- When operation starts, the flap direction is fixed at the horizontal position in order to avoid cold draft, and return to the set the position that was set
 after the warm air supply is starting.
- The flap direction will be controlled to the horizontal position when the room temperature reaches the set temperature and compressor stops or when
 defrosting is in operation.
- The airflow direction cannot be set during the period mentioned above. Change the airflow direction settings after the warm air is supplied and the
 flap goes to the set position.

MEMORY FLAP (FLAP STOPPED)

When you press the AIRFLOW button once while the flap is operating, it stops swinging at the position. Since this angle is memorized in the microcomputer, the flap will automatically be set at this angle when the next operation is started.


- ⚠ WARNING-


• Do not expose directly to airflow from the air-conditioner for a long time.

_ A CAUTION

- When in COOL or DRY operation, do not operate for a long period with the airflow blowing straight down. Otherwise, condensation may appear on the outlet grill and drip down.
- Do not try to adjust the flaps by hand, as the control angle may change or the flap may not be closed completely.


· Recommended angle of the flap when stopping





Adjusting left/right air flow direction

Adjust the direction by moving the left/right louver by hand. When you adjust the direction, touch the operation point of louver.



△ CAUTION

• Please stop the air conditioner when adjusting the air flow direction.

EEP TIMER operation

■ The unit stops automatically after the set time lapses.

The set temperature is automatically adjusted according to the elapsed time in order to avoid too much cooling or heating. Page 15





Changing of set time

Set a new time by pressing SLEEP button.

How to cancel

Press the CANCEL button to turn off the SLEEP display.

Press the SLEEP button.

■ If it is pressed while the unit is off

SLEEP TIMER operation starts with the previous operation settings, and the air conditioning is turned off after the set time elapses.

■ If it is pressed while the unit is running

The air conditioner is turned off after the set time elapses.

Every time the button is pressed, the display changes as follows:



Example: You prefer it to stop after 7 hours.

The timer light (yellow) is on.



· The unit stops after the set time lapses.



Cannot be set at the same time with OFF-TIMER.

OFF-TIMER operation

The unit stops automatically when the set time comes. With the air conditioner turned off, start the operation from Step 1. With the air conditioner running, start from Step 2.

Example: You prefer it to stop 22:30.

A MITSUBISHI FAN SPEED ON/OFF CLEAN ♦& ACL

Press the ON/OFF button.

Press the OFF TIMER button.

Press the \triangle or \bigcirc button.

OFF TIMER display OFF is blinking.

Every time the button is pressed, the display is switched in the order of:

 $\rightarrow 0:00 \longrightarrow 0:10 \longrightarrow 0:20 \longrightarrow \cdots \longrightarrow 1:00 \longrightarrow 1:10 \longrightarrow (Units of ten minutes)$

Every time the ♥ button is pressed, the display is switched in the order of:

>0:00→23:50→23:40→ ··· →23:00→22:50→ (Units of ten minutes)

Set at 22:30.

Press the OFF TIMER button.

The display changes from blinking to steady lighting and the setting is complete. The timer light (yellow) is on.

Changing of set time

Set a new time by using the OFF TIMER button.

How to cancel -

Press the CANCEL button to turn off the timer display.

NOTE

- The unit stops at the end of the set period of time.
- Make sure to press the button within 60 seconds from the last operation in step 3, otherwise the setting is not completed.
- The current time is not displayed during OFF-TIMER operation.

 Different from SLEEP TIMER operation, automatic set temperature adjustment is not done during OFF-TIMER operation.

TIMER operation

Operation starts 5 to 60 minutes before the set time so that the room temperature reaches the optimum temperature at the set time. Page 15 ON-TIMER operation can be set regardless of whether the air-conditioner is running or not.



Press the ON-TIMER button.

ON TIMER display (IN) is blinking.

Press the \triangle or \bigcirc button.

Every time the \(\triangle \) button is pressed, the display is switched in the order of:

 $0:00 \longrightarrow 0:10 \longrightarrow 0:20 \longrightarrow \cdots \longrightarrow 1:00 \longrightarrow 1:10 \longrightarrow (Units of ten minutes)$

Example: In the case the preferred room temperature is required at 8:00.

Every time the ♥ button is pressed, the display is switched in the order of:

•0:00→23:50→23:40→ ··· →23:00→22:50→ (Units of ten minutes)

Set at 8:00

Press the ON TIMER button.

The display changes from blinking to steady lighting and the setting is complete.

The timer light (yellow) is on.

The operation stops if it is set during operation.

NOTE

Operation starts 5 to 60 minutes before the set time.

The timer light (yellow) goes out at the set time.

- Make sure to press the button within 60 seconds from the last operation in step 2, otherwise the setting is not completed.
- The current time is not displayed during ON-TIMER operation.

Changing of set time -

A MITSUBISHI

ON/OFF

TEMP

CANCEL

FAN SPEED

ESP HI POWER

econo

Set a new time by using the ON-TIMER button.

ACI

How to cancel -

CLEAN ♦औ

Press the CANCEL button to turn off the timer display.

TIMER + ON-TIMER operation

■ Combined timer operation of SLEEP TIMER and ON TIMER.

Example: When it is required to stop after 3 hours and then start operation at 8:00, near the set temperature.



Set by the procedures on page 13.

Set to

■ ON TIMER operation setting

Set by the above procedure mentioned in ON TIMER.

Set to (1) ON

The setting of the lighting of the timer light (yellow) of this unit is complete.

After the SLEEP TIMER set time has elapsed, the operation stops, and

- it starts from 5 to 60 minutes before the ON TIMER's set time.
- The timer light is turned off when ON TIMER set time comes.



Changing of set time -

Set a new time by using the SLEEP or ON TIMER button.

How to cancel

Press the CANCEL button to turn off the timer display.

PROGRAM TIMER operation

■ The timer operations of the combination of ON and OFF TIMER. Once this has been set the timer operations will be repeated at the same time every day unless the ON/OFF button is pressed.

Example: When it is prefered to stop at 22:30, and then start operation at 8:00, near the set temperature.



■ OFF TIMER operation setting

Set by the procedures on page 13. Set to OFF.

■ ON TIMER operation setting

Set by the procedures on page 14. Set to ⊕ (ON)

Timer light (yellow) on the unit will light when the setting is completed.

The set time will be displayed on the remote control unit. The display will change depending on the operational status.

④0N▶0FF **B:**[[[]]

With ON TIMER, the air conditioner starts running. Then, with OFF TIMER, the air conditioner stops running.



With OFF TIMER, the air conditioner stops running. Then, with ON TIMER, the air conditioner starts running.

Changing of set time -

Set a new time by using the OFF TIMER or ON TIMER button.


- How to cancel -

Press the CANCEL button to turn off the timer display.

Comfort Start-up

In ON TIMER operation, the unit starts the operation a little earlier, so that the room can approach optimum temperature at ON time. This is so called "Comfort start-up".

- Mechanism
 - The room temperature is checked 60 minutes before the ON time. Depending on the temperature at that time, the operation starts 5 to 60 minutes before the timer is at ON.
- The function is available for both COOL and HEAT operation mode (including AUTO). It does not work for DRY mode.




SLEEP TIMER

When SLEEP TIMER is selected, the set temperature is automatically adjusted after a while, ensuring that the room is not too cold during cooling or too warm during heating.

- During cooling: The preset temperature is lowered by 1°C at the start of SLEEP operation (when the timer is set). After that, the temperature goes up by 1°C every an hour to become 1°C higher than the present temperature.
- During heating: The preset temperature is lowered by 1°C at the start of SLEEP operation (when the timer is set). After that the temperature becomes 3°C lower in an hour and 6°C lower in two hours than the present temperature.

HIGH POWER/ECONOMY operation



If the air-conditioner is not operating, point the remote control toward the air conditioner, and

1

Press the ON/OFF button.

2

Press the HI POWER/ECONO button.

When the operating mode is AUTO, COOL or HEAT
 Every time the HI POWER/ECONO button is pressed, the display is switched in the order of:



 When the operating mode is DRY or PROGRAM TIMER Every time the HI POWER/ECONO button is pressed, the display is switched in the order of:



Concerning HIGH POWER operation

Pressing the HI POWER/ECONO button intensifies the operating power and initiates powerful cooling or heating operation for 15 minutes continuously. The remote control (displays and the FAN SPEED display disappears.



- During the HIGH POWER operation, the room temperature is not controlled. When it causes an excessive cooling or heating, press the HI POWER/ECONO button again to cancel the HIGH POWER operation.
- HIGH POWER operation is not available during the DRY and the program timer operations.
- When HIGH POWER operation is set after ON TIMER operation, HIGH POWER operation will start from the set time.
- When the following operations are set, HIGH POWER operation will be canceled.
 - ① When the HI POWER/ECONO button is pressed again.
 - 2 When the operation mode is changed.
 - 3 When it has been 15 min. since HIGH POWER operation has started.
- · Not operable while the air conditioner is OFF.

Concerning ECONOMY operation

Pressing the HI POWER/ECONO button initiates a soft operation with the power suppressed in order to avoid an excessive cooling or heating. The unit operates 1.5°C higher than the setting temperature during cooling or 2.5°C lower than that during heating. The remote control em displays and the FAN SPEED display disappears.




- It will go into ECONOMY operation at the next time the airconditioner runs in the following case.
 - ① When the air-conditioner is stopped by ON/OFF button during ECONOMY operation.
 - When the air-conditioner is stopped in SLEEP or OFF TIMER operation during ECONOMY operation.
 - 3 When the operation is retrieved from CLEAN operation.
- When the following operations are set, ECONOMY operation will be canceled.
 - When the HI POWER/ECONO button is pressed again.
 - ② When the operation mode is changed from DRY to FAN
- · Not operable while the air conditioner is OFF.

SELF CLEAN operation


CLEAN operation should be run after AUTO, COOL and DRY operation to remove the moisture from inside the indoor unit and control the growth of mold and bacteria.





NOTE

- Two hours later, the air conditioner stops running automatically. To stop the air conditioner immediately, press the ON/OFF button.
- CLEAN operation is not operated after HEAT, FAN, OFF-TIMER and SLEEP operations have finished.
- The indoor unit fan runs for about two hours in CLEAN operation.
- · The RUN light illuminates during CLEAN operation.



- Pressing the SLEEP button during CLEAN operation cancels the CLEAN operation and then the unit is set to SLEEP operation.
- This is not a function for removing mold, germs or grime that have already adhered to the unit.

Auto restart function

■ What is auto restart function?

- Auto restart function records the operational status of the air-conditioner immediately prior to be switched off by a power cut, and then
 automatically resumes operations after the power has been restored.
- The following settings will be canceled:
 - 1 Timer settings
 - ② HIGH POWER operations



- Auto restart function is set at on when the air-conditioner is shipped from the factory. Consult with your dealer if this function needs
 to be switched off.
- · When power failure occurs, the timer setting is canceled. Once power is resumed, set the timer again.

Tips for effective operation

■ Please observe the following for the most economic and comfortable use of your unit.

Set a suitable room temperature.	Clean the filter frequently.	Avoid direct sunlight and draught.
Excessively high or low temperatures are not good for your health and waste of electricity.	Clogged filter may block the airflow and cause less efficient operation.	Cut out direct sunlight by drawing the curtains or blinds when cooling. Keep windows and doors shut, except when ventilating.
Adjust the airflow direction properly.	Operate the unit only when needed.	Keep heat source away when cooling.
Adjust the up/down and left/right airflow to ensure a steady room temperature.	Use the timer properly to operate the unit only when needed.	Keep heat sources out of the room as much as possible.

Maintenance

Carefull matter during maintenance

Turn off the power supply.



· Do not spill any liquid.

Wipe the unit with a soft, dry cloth.





- Do not touch the aluminum fins on the heat exchanger.
- · Stand firmly on a stepladder or other stable object when removing the filter.

Do not use the following articles:

- Hot water (40°C or more)
- It may deform or discolour the unit.
- Petrol, paint thinner, benzine or cleanser, etc. They may deform or scratch the unit.

During the operational season



Cleaning the air filter Recommendation interval is once every two week

Hook fingers on this side of the top face of air filter. Pull the air filter forward. The air filter will separate from front panel.

- Mhen removing the air filter, pull it out gently without tilting and with care not to shake off dirt
- accumulated on the air filter.


 Be careful not to allow dirt shaken off the air filter entering in the eves or mouth.



Cleaning

Remove dirt from the air filter using a vacuum cleaner. If the filter is very dirty, clean it with warm water (approx. 30°C), and dry it thoroughly.

- Do not dry them over an open flame.
- Pull them out gently.




Reinstall the air filter

Insert the air filter's ditch to the rail of the front panel and push it in the back.



- A CAUTION

Operating without putting back the air filter will make the unit dusty, and may cause damage.



Cleaning the unit

- Wipe the unit with a soft, dry cloth, or use a vacuum cleaner.
- If the unit is very dirty, wipe it with a cloth soaked in warm water.



Cooling/heating is affected by an air filter clogged up with dust etc., and the operation noise becomes louder. It may also use extra electricity. Please clean the air filter at recommendation intervals.

At the end of the season

Perform the fan operation for a half day.

Dry the inside of the unit. Cooling season only.

Stop the unit and turn off the power supply.

The unit consumes approx. 2W even when the unit is not operating. Turning off the power supply will help saving energy consumption and cost

Clean and reinstall the air filter.

Clean both the indoor and outdoor units.

Remove batteries from the remote control.

At the beginning of the season

Make sure that there are no obstacles blocking the airflow around the air intake and outlet openings of the indoor and outdoor units.

Check if there is no corrosion or rust on the base frame of the outdoor unit.

Ensure that the earth wiring is not snapped nor disconnected.

Ensure that the air filter are clean.

Turn on the power supply.

Insert batteries in the remote control.

Proper installation

Suitable installation position

- Do not put any obstruction in front of the indoor unit, preventing proper ventilation and functioning.
- Do not install the unit in any of the following places:
 - · Where there is a danger of leaking flammable gases.
 - · Where there is substantial splashing of oil.
- Malfunctioning due to corrosion may occur if the unit is installed in a spa where sulfide gases are generated, or in a seaside resort
 exposed to sea breezes. Contact your dealer.
- The air-conditioner and remote control must be at least 1 metre away from a TV set or radio.
- . Drain the dehumidified liquid from the indoor unit into a spot that drains well.

Pay attention to operating noises!

- When you install the unit, take care to choose a place that can comfortably stand the weight of the unit and does not increase the operating noise
 or vibration. If vibration is transmitted through the house, fix the unit with the aid of vibration-proof pads between the unit and the fittings.
- Select a place where cold or hot air, operation noises from the indoor and outdoor units do not cause any inconvenience to your neighbours.
- · Do not leave any obstacles near the outlet and inlet of the outdoor unit. This may cause malfunctioning and increased operating noise.
- · If you hear an irregular noise during operation, contact your dealer.

Inspection and maintenance

Depending on operating environment, the inside of the air-conditioner may become dirty after a few year operations. This will reduce performance. In addition to normal cleaning, we would recommend inspection and maintenance. (This may lead the air-conditioner to having a longer life without any trouble.)

- Contact your dealer, or any distributor, for inspection and maintenance. (There will be a charge for this service).
- · We would recommend inspection and maintenance to be carried out during the off-season.
- If the supply cord of this appliance is damaged, it must only be replaced by a repair shop appointed by the manufacturer, because special purpose tools are required.

Troubleshooting

Please carry out the following checks before making a service call.

The air-conditioner does not work at all.			
Has the power switch been turned off?	Has the timer been set in the "ON" position?	Is there a power failure or a blown fuse?	

Poor cooling or heating		
Have you set the thermostat at a suitable temperature?	Is the air filter clean? (Not clogged?)	Did you leave any doors or windows open?

Poor cooling		
Is there any direct sunlight entering the room?	Is there a heat source in the room?	Are there too many people in the room?

If the air-conditioner does not operate properly after you have checked the above points, or if any doubt still exists after you have consulted page 20, or if things happen as shown on page 21, switch off the power and contact your dealer.

An alternative refrigerant (R410A) is used in this air-conditioner. When asking your dealer for service or inspection and maintenance, explain the dealer about it.

Notice

The unit does not restart immediately after you have stopped it. (RUN light is on)	Restart is blocked for 3 minutes after you have stopped the operation to protect the unit. The three-minute protection timer in the microcomputer automatically starts it up again.
(HOTT light to on)	mandany dianto it up again.
Airflow is not blown out when starting the HEATING operation.	Airflow has stopped to prevent blowing out of cold air until the indoor heat exchanger has warmed up. (2 to 5 min.) (HOT
RUN light blinks slowly (1.5 sec ON, 0.5 sec OFF)	KEEP program)
Airflow is not blown out for 5 to 10 min. or blown out not warm wind for a moment at HEATING operation.	When outdoor temperature is low and humidity is high, the unit sometimes performs defrosting automatically. Please wait. Dur-
RUN light blinks slowly (1.5 sec ON, 0.5 sec OFF)	ing defrosting, water or steam may escape from the outdoor unit.
Airflow is not blown out when starting the DRY operation.	The indoor fan may stop to prevent re-evaporation of dehumified moisture and to save energy.
(RUN light is on)	modulo and to bare oneigh.
Some steam escapes during COOL operation.	This may occur if the room's temperature and humidity are very high. It disappears as soon as the temperature and humidity decrease.
There is a slight smell.	Air blown out during operation may smell. This is caused by tobacco or cosmetics adhering to the unit.
You hear a slight gurgling sound.	This is caused by refrigerating liquid moving within the unit.
You hear a slight cracking sound.	This is caused by heat expansion or contraction.
You hear a hissing or clicking sound.	This is caused by the operation of the refrigerant control valves or electric components.

After a power cut, the unit does not restart even if power has been restored.	If the auto restart function is not set, the unit will not restart automatically. Use the remote control to start the operation again.
Remote control signals are not received.	Remote control signals may not be received if the signal receiver on the air-conditioner is exposed to direct sunlight or other bright light. If so, cut out the sunlight or reduce the other light.
Moisture may form on the air outlet grills.	If the unit is operated for a long time in high humidity, moisture may form on the air outlet grills and start dripping.
Whistling noise is heard from the outdoor unit.	The noise means that the revolution speed of the compressor is increasing or decreasing.
Fan will not stop immediately after unit operation was stopped.	Indoor fan : Fan will not stop after 2 hours if set to CLEAN operation. Outdoor fan : Fan will not stop about a 1 minute period in order to protect the unit.
RUN light stays on even though operation was stopped.	The RUN light illuminates during CLEAN operation. Run light turns off when CLEAN operation ends.


Contact your dealer

■ Turn off the power switch immediately and inform your dealer in any of the following situations:

The cable becomes extremely hot. The covering of the cable is cracked.	If the power cord	becomes damaged, ask your dealer or a qualified engineer to
		ment to avoid accidents.
The fuse or switch blows continuously.		The TV, radio or other equipment starts to malfunction.
A switch does not activate properly.		You hear a strange noise during operation.
When abnormalities occur, turn off the power supply immediately and turn it on after 3 minutes. Restart the operation with ON/OFF button of the remote control and the abnormalities still continue.		The RUN and TIMER lights on the unit display section blink quickly (0.5 sec. ON; 0.5 sec. OFF) and do not work.

Self diagnosis function

We are constantly trying to do better service to our customers by installing such judges that show abnormality of each function as follows:





MITSUBISHI HEAVY INDUSTRIES, LTD.

AIR-CONDITIONING & REFRIGERATION DIVISION

3-1, Asahi, Nishibiwajima-cho, Kiyosu, Aichi, 452-8561, Japan http://www.mhi.co.jp

MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONING EUROPE, LTD.

7 Roundwood Avenue, Stockley Park, Uxbridge, Middlesex, UB11 1AX, United Kingdom

Tel:+44-20-7025-2750 Fax:+44-20-7025-2751 http://www.mhiae.com

MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONERS AUSTRALIA, PTY. LTD.

9C Commercial Road Kingsgrove NSW 2208 PO BOX 318 Kingsgrove NSW 1480

Tel:+61-2-8571-7977 Fax:+61-2-8571-7992 http://www.mhiaa.com.au